# TOP AND CONSOLE PARTS

ELECTRIC DRYER

**For Models: GEW9250PW0, GEW9250PL0, GEW9250PT0**
**(White/Platinum) (Pewter) (Biscuit)**







WIRING HARNESS PARTS




**FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST**

# TOP AND CONSOLE PARTS

**For Models: GEW9250PW0, GEW9250PL0, GEW9250PT0**
**(White/Platinum) (Pewter) (Biscuit)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | | Literature Parts |
| | 8530051 | Use & Care Guide |
| | 8558722 | Tech Sheet |
| 2 | | Top |
| | 8519251 | White |
| | 3980096 | Pewter |
| | 8519252 | Biscuit |
| 3 | 8529983 | Harness, Main |
| 4 | | Panel, Console |
| | 8558748 | Platinum |
| | 8558751 | Pewter |
| | 8558750 | Biscuit |
| 5 | 3394427 | Clip, Harness |
| 6 | 8519271 | Bracket, Console |
| 7 | 353424 | Connector, Sensor |
| 8 | 94614 | Terminal |
| 9 | 3936144 | Plug, Terminal |
| 10 | 94613 | Terminal |
| 11 | 3390647 | Screw, 8−18 x 1/2 |
| 12 | 488886 | Screw, 8−18 x 1/2 |
| 13 | 8519406 | Bezel, Cycle |
| 14 | 3936150 | Connector, 7−Circuit |
| 15 | 3395683 | Connector, (Motor) |
| 16 | 8281225 | Screw, 8−18 x 1/2 |
| 17 | 2203186 | Connector, 5−Circuit |
| 18 | | Knob, Assembly |
| | 46197020472 | Platinum |
| | 46197020742 | Pewter |
| | 46197020741 | Biscuit |
| 19 | | User Interface |
| | 8558753 | Platinum |
| | 8558756 | Pewter |
| | 8558755 | Biscuit |
| 20 | 8561811 | Button, Start |
| 21 | 8561812 | Button, Pause/Cancel |

# CABINET PARTS

**For Models: GEW9250PW0, GEW9250PL0, GEW9250PT0**

**(White/Platinum) (Pewter) (Biscuit)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

**For Models: GEW9250PW0, GEW9250PL0, GEW9250PT0**
**(White/Platinum) (Pewter) (Biscuit)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 8317342 | Cover, Terminal Block |
| 2 | 3390814 | Screw, 8−18 x 3/8 |
| 3 | 697776 | Screw, 10−32 x 5/8 (Ground) |
| 4 | 3397659 | Block, Terminal |
| 5 | 3394881 | Switch, Broken Belt |
| 6 | 8521959 | Dry Rack (Top) |
| 7 | | Panel, Side (L.H.) |
| | 8519209 | White |
| | 8519216 | Pewter |
| | 8519210 | Biscuit |
| 8 | 3392100 | Foot, Dryer |
| | 279810 | Foot − Optional (Extended Length Package Of 2) (Not Included) |
| 9 | 660658 | Clamp, Motor (2) |
| 10 | 3387374 | Spring, Idler |
| 11 | 3389420 | Retainer, Idler |
| 12 | | Plug, Multivent |
| | 697750 | White |
| | 3979261 | Pewter |
| | 3388311 | Biscuit |
| 13 | 3388672 | Pulley Assembly |
| 14 | 279318 | Terminal, Brass & Tinned (3) (Includes Illus. 33) |
| 15 | 8066120 | Lever, Snap Switch |
| 16 | 3394081 | Wire, Belt Switch |
| 17 | 8528076 | Sound Panel |
| 18 | 233520 | Washer, Thrust |
| 19 | 8283288 | Wire, Jumper (Includes Illus. #41) |
| 20 | 690997 | Tri Ring |
| 21 | 8066115 | Cover−Plate |
| 22 | 8529053 | Ramp, Door |
| 23 | 8521961 | Dry Rack Support |
| 24 | | Panel, Side (R.H.) |
| | 8519213 | White |
| | 8519217 | Pewter |
| | 8519214 | Biscuit |
| 25 | 8521957 | Dry Rack Assembly |
| 26 | 3393657 | Restrainer, Belt |
| 27 | 8538263 | Motor, Assembly 60 HZ. |
| 28 | 3398948 | Wire, Jumper (Broken Belt Switch) |
| 29 | 3389729 | Pulley 60 HZ. |
| 30 | 3387610 | Belt, Drive |
| 32 | 3387118 | Bracket, Motor |
| 33 | 279393 | Terminal Block Screw Kit (For Terminal Block) |
| 34 | 49026 | 4" − 90° Elbow |
| 36 | 3395532 | Exhaust Pipe & Bracket |
| 37 | 3395534 | Exhaust Pipe (Short) |
| 38 | 3395535 | Exhaust Pipe (Long) |
| 39 | 3388674 | Idler Bracket |
| 41 | 8519323 | Switch, Door |
| 42 | 98129 | Screw, 6−20 x 1 1/16 |
| 43 | 3390647 | Screw, 8−18 x 1/2 |
| 44 | 3387242 | Seal, Front Panel |
| 45 | 3393008 | Screw, 10−16 x 1/2 |
| 46 | 8519459 | Clip, Toe Panel |
| 50 | 8519207 | Base, Cabinet |
| 51 | | Front Panel |
| | 8562167 | White |
| | 8562169 | Pewter |
| | 8562168 | Biscuit |
| 52 | 696144 | Strike, Door (2) |
| 53 | 90767 | Screw, 8−18 x 3/8 |
| 55 | 8299925 | Harness, Digital Interface |
| 56 | 8519273 | Bracket, Control |
| 57 | 8546219 | Control Board |
| 59 | 3400826 | Screw, 8−18 x 3/4 |
| 61 | | Toe, Panel |
| | 8519233 | White |
| | 3980095 | Pewter |
| | 8519234 | Biscuit |
| 62 | 8519219 | Panel, Rear |
| 63 | 692400 | Nut, Push−In |
| 64 | 343641 | Screw, 10−16 x 1/2 |

## Optional Parts Not Included

### Dryer Exhaust Kit (For Side & Bottom Venting)

| | | |
|---|---|---|
| 66 | 279818 | White |
| | 279969 | Pewter |
| | 279925 | Biscuit |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

**For Models: GEW9250PW0, GEW9250PL0, GEW9250PT0**

**(White/Platinum) (Pewter) (Biscuit)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

**For Models: GEW9250PW0, GEW9250PL0, GEW9250PT0**
**(White/Platinum) (Pewter) (Biscuit)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 3399508 | Shaft, R.H. Thread |
| 2 | 3390647 | Screw, 8−18 x 1/2 |
| 3 | 3394984 | Door, Lint Screen |
| 4 | 3406653 | Harness, Sensor |
| 5 | 697354 | Air Duct Assembly |
| 6 | 697813 | Seal, Outlet Housing |
| 7 | 697814 | Seal, Drum Front |
| 8 | 3359452 | Nut,3/8 x 16(R.H.) |
| 9 | 8066086 | Drum Hole Plug |
| 10 | 3402841 | Lens, Drum Light |
| 11 | 359625 | Screw, 8−18 x 1/2 |
| 12 | 3388229 | Clip, Exhaust Pipe |
| 13 | 3390646 | Screw, 8−18 x 5/16 |
| 14 | 3387747 | Heater Element |
| 15 | 279457 | Terminal Wire Kit (For Heater Element Wiring Harness Repair) |
| 16 | 3387709 | Nut, 3/8−16 (L.H.) |
| 17 | 8520836 | Bulkhead, Rear |
| 18 | 3387459 | Washer, Support |
| 19 | 3399509 | Shaft, L.H. Thread |
| 20 | 690997 | Ring, Tri |
| 21 | 8536973 | Roller, Support |
| 22 | 3402715 | Exhaust Pipe |
| 23 | 3394985 | Housing, Outlet |
| 24 | 8529007 | Plug, Rear Bulkhead |
| 25 | 8299966 | Complete Drum Assembly |
| 26 | 97787 | Screw, 11−16 x 3/4 |
| 27 | 697694 | Seal, Drum |
| 28 | 695240 | Screw, 8−18 x 1/2 |
| 29 | 90767 | Screw, 8−18 x 3/8 |
| 30 | 8519221 | Channel Bracket, Rear Bulkhead (2) |
| 31 | 8519275 | Bracket, Upper Rear Bulkhead |
| 33 | 3406124 | Bulb, Light |
| 34 | 3387223 | Electrode, Sensor |
| 35 | 3977373 | Bracket, Drum Light |
| 36 | 3403634 | Socket Assembly |
| 37 | 697772 | Wheel, Blower |
| 39 | 3394986 | Spring, Lint Screen Door |
| 42 | 3976615 | Thermistor |
| 43 | 487909 | Screw, 8−15 x 1/2 |
| 44 | 8544362 | Housing, Blower |
| 45 | 8066168 | Lint Duct Assembly |
| 46 | 3392537 | Heater Box |
| 47 | 8318314 | Thermal Cut−Off (Includes Illus. 48) |
| 48 | 3391914 | Thermostat 295°F (146°C) |
| 49 | 8066099 | Bracket, Heater Box |
| 51 | 3387230 | Screw, 10−16 x 1 |
| 53 | 697693 | Baffle, Drum |
| 54 | 8519245 | Bulkhead, Front |
| 58 | 8299979 | Grill, Outlet |
| 59 | 3392519 | Thermal Fuse |
| 60 | 697770 | Seal, Cover Plate |
| 64 | 8066170 | Lint, Screen |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

**For Models: GEW9250PW0, GEW9250PL0, GEW9250PT0**
**(White/Platinum) (Pewter) (Biscuit)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 8563855 | Plug, Strip |
| 2 | 8559709 | Door Hinge Assembly |
| 3 | 342043 | Screw, 10−32 x 3/8 |
| 4 | 9742177 | Screw, 8−18 x 5/8 |
| 5 | 8529539 | Bracket, Handle |
| 7 | | Handle, Door (LH) |
| | 8559739 | Platinum |
| | 8559743 | Pewter |
| | 8559741 | Biscuit |
| | | (Following Parts Not Included) |
| | | Handle, Door (RH) |
| | 8559738 | Platinum |
| | 8559742 | Pewter |
| | 8559740 | Biscuit |
| 8 | 3357011 | Screw, 10−16 x 1/2 |
| 9 | | Door Assembly (Outer) |
| | 8541574 | Platinum |
| | 3980079 | Pewter |
| | 3977873 | Biscuit |
| 10 | 8546200 | Door Assembly (Inner) (Includes Illus. 12) |

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 11 | 355515 | Screw, 8−18 x 11/16 |
| 12 | 3389441 | Door Catch Assembly |
| 14 | 8529540 | Badge, Assembly |
| 15 | | Filler Handle (LH) |
| | 8528289 | Platinum |
| | 3980082 | Pewter |
| | 3979771 | Biscuit |
| | | (Following Parts Not Included) |
| | | Filler Handle (RH) |
| | 8528287 | Platinum |
| | 3980101 | Pewter |
| | 3979772 | Biscuit |
| 16 | | Cover−Hinge, Stationary (RH) |
| | 8559713 | Platinum |
| | 8559719 | Pewter |
| | 8559717 | Biscuit |
| | | (Following Parts Not Included) |
| | | Cover−Hinge, Stationary (LH) |
| | 8559712 | Platinum |
| | 8559718 | Pewter |
| | 8559716 | Biscuit |

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 17 | | Cover−Hinge, Rotating |
| | 8559722 | Platinum |
| | 8559724 | Pewter |
| | 8559723 | Biscuit |
| 18 | 8547091 | Clip, Trim Panel |
| 19 | | Trim & Clip Assembly (Lower) |
| | 8558683 | Platinum |
| | 8558685 | Pewter |
| | 8558684 | Biscuit |
| 20 | | Trim & Clip Assembly (LH) |
| | 8558687 | Platinum |
| | 8558692 | Pewter |
| | 8558690 | Biscuit |
| 21 | | Trim & Clip Assembly (RH) |
| | 8558689 | Platinum |
| | 8558693 | Pewter |
| | 8558691 | Biscuit |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# PEDESTAL PARTS (NOT INCLUDED)

**For Models: GEW9250PW0, GEW9250PL0, GEW9250PT0**
**(White/Platinum) (Pewter) (Biscuit)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | | Literature Parts |
| | LIT8537141 | Installation Instructions |
| | LIT8537342 | Parts List |
| 2 | | Drawer Front Assembly |
| | 8537870 | White |
| | 8537871 | Biscuit |
| | 8537872 | Graphite |
| | 8537908 | Pewter |
| | 8537931 | Meteorite |
| 3 | | Drawer Bin |
| | 8537883 | For Model Numbers LAB2700MQ, LAB2700MT, LAB2700MK and LAB2700ML |
| | 8537934 | For LAB2700PMT |
| 4 | | Divider, Drawer (Set Of 2) |
| | 8537875 | For Model Numbers LAB2700MQ, LAB2700MT, LAB2700MK and LAB2700ML |
| | 8537935 | For LAB2700PMT |
| 5 | 8537850 | Slide Assembly |
| 6 | 3400111 | Screw |
| 7 | 8537852 | Foot Assembly |
| 8 | 3400639 | Screw, 6−20 x 3/8 |
| 9 | | Cabinet (Not Serviced) |
| 10 | 3400842 | Screw, 8−18 x 1/2 |
| 11 | 8537863 | Pad (4) |
| 12 | 8537853 | Pan, Bottom |
| 13 | 9740848 | Screw |
| 14 | 90767 | Screw |

# OPTIONAL PARTS (NOT INCLUDED)

**For Models: GEW9250PW0, GEW9250PL0, GEW9250PT0**
**(White/Platinum) (Pewter) (Biscuit)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| | | **PAINT, TOUCH−UP (1/2oz.)** |
| | 72017 | White |
| | 4396174 | Pewter |
| | 4392899 | Biscuit |
| | | **PAINT, PRESSURIZED SPRAY (12 oz.)** |
| | 350930 | White |
| | 4396175 | Pewter |
| | 4392901 | Biscuit |
| | 350938 | Primer, Gray |
| | | **PAINT, BULK (1 qt.)** |
| | 799344 | White (Uncut) |
| | 4392900 | Biscuit (Uncut) |
| | | **ACCESSORY PARTS** |
| | 8529894 | Kit, Hold Down |
| | 8541503 | Kit, Stack Assembly Kit, Door Reversing |
| | 8530070 | Platinum |
| | 8530072 | Pewter |
| | 8530071 | Biscuit |
| | 80047 | Kit, Dryer Repair |